

ООО "Фотооптик"

Оператор: Бачинская И. Изм. контрольное стекло. Партия D-027. Покрытие Т 720-В (L34). Дата 10.11.13

Прибор: Shimadzu UV-3600

WL,nm	T, %
400	87.67
405	89.90
410	92.54
415	87.47
420	87.50
425	91.96
430	92.62
435	86.80
440	86.80
445	88.93
450	92.78
455	93.17
460	89.00
465	93.76
470	94.91
475	95.27
480	90.36
485	89.20
490	93.16
495	90.57
500	92.00
505	90.48
510	95.81
515	95.92
520	96.17
525	95.13
530	94.41
535	95.89
540	94.85
545	91.98
550	92.27
555	94.32
560	94.43
565	93.78
570	94.11
575	93.93
580	92.98
585	93.18
590	94.44
595	94.45
600	93.16
605	93.03
610	94.65
615	95.54
620	94.12
625	92.07
630	91.80
635	93.37
640	95.07
645	95.36
650	94.42
655	93.34
660	92.88

WL,nm	T, %
670	93.73
675	94.16
680	94.04
685	93.87
690	94.18
695	94.73
700	94.32
705	90.93
710	80.12
715	56.55
720	29.89
725	12.93
730	5.88
735	2.94
740	1.61
745	0.97
750	0.64
755	0.46
760	0.34
765	0.27
770	0.22
775	0.19
780	0.16
785	0.15
790	0.14
795	0.14
800	0.15
805	0.15
810	0.15
815	0.15
820	0.12
825	0.086
830	0.058
835	0.039
840	0.022
845	0.019
850	0.010
855	0.009
860	0.003
865	0.011
870	0.009
875	0.003
880	0.007
885	0.007
890	0.005
895	0.019
900	0.004
905	0.011
910	0.017
915	0.022
920	0.024
925	0.032
930	0.07

WL,nm	T, %
940	0.24
945	0.58
950	1.94
955	4.42
960	3.17
965	1.50
970	0.94
975	0.72
980	0.63
985	0.64
990	0.70
995	0.83
1000	1.05
1005	1.47
1010	2.20
1015	3.57
1020	6.04
1025	9.34
1030	11.06
1035	9.62
1040	7.38
1045	5.74
1050	4.85
1055	4.41
1060	4.32
1065	4.50
1070	4.94
1075	5.70
1080	6.98
1085	8.98
1090	12.11
1095	16.84
1100	24.15
1105	33.27
1110	43.17
1115	50.05
1120	51.29
1125	48.72
1130	45.44
1135	43.18
1140	42.53
1145	43.60
1150	46.66
1155	51.81
1160	59.10
1165	68.32
1170	77.93
1175	86.20
1180	91.46
1185	91.80
1190	87.55
1195	80.84
1200	74.02

